



Wash Station Instructions

At the start of a session:

1. Fill the water storage container with water and submerge the pump in the water.
2. Plug the power cable into the unit and at the other end into a powerpoint.
3. Make sure the gas is connected to the unit. Turn the nozzle on the gas bottle to OPEN.
4. Make sure the temperature dial on the unit is set to MAX.

Then:

5. Switch on the ON switch on the unit.
There should be a quiet hum in the pump.
6. Turn on the shower nozzle.
There should be a ticking sound as the gas heater ignites and after maybe 10-20 seconds of the water running, it should start to come through hot.

Leave the unit switched on, and hot water should flow whenever you turn on the shower nozzle.

Cleanup at the end:

1. Turn the switch on the unit to OFF.
2. Turn the nozzle on the gas bottle to CLOSED.
3. Unplug the power cable and store in the grey bag.
4. Take the pump out of the water and tip out any leftover water.

Troubleshooting- If something is wrong:

Water doesn't come through hot- the gas could have run out. Replace the gas.

No hum when you turn it on. It may have blown a fuse. There are a couple of spare fuses in the grey supply bag. The fuse is in the tip of the car adaptor on the power cable. Switch off power to change it or call Vic Park Collective volunteer, Erin Stinton on 0455 840 632.